

This frame is for an in ground standard 6' high set. You will need to specify colors for the End Frame Fittings, Swing Chain and Commercial Swing Seat. This product should last 2 years in harsh conditions and up to 5 years in optimal conditions. Some conditions may require replacement sooner.

TOOLS AND PARTS NEEDED:

Ladder, 3/4" wrench, Ratchet socket wrench, Tape measure, supplied Allen wrench for shackles, and 6mm Allen wrench for set screws. Stakes for marking holes. Shovel Bricks, Gravel, and Wheelbarrow for mixing concrete, Water, Concrete, Trowel, Level, Warning signs. Protective surfacing according to ASTM F1292 for a fall height of 6'.

MEASUREMENTS FOR SWING FRAME:

The legs are 133" apart lengthwise at ground level. The legs are 69" wide at ground level. Below ground, the legs are 150" lengthwise and the width below ground is 93". Height is 6'

****INSTALLATION, SAFE USE & MAINTENANCE INSTRUCTIONS****

IMPORTANT: To keep children safe from harm, follow these precautions and instructions when installing, using, or maintaining this playground equipment. You can also call us at 1-800-433-2573 for more information or see <http://www.cpsc.gov/cpscpub/pubs/324.pdf>.

Installation: Read all instructions before attempting assembly. To determine proper use zones needed for swing set consult Figure 23, Table 7 for commercial swing sets. For residential sets see spacing dimensions on Page 4 of the Outdoor Home Playground Safety Handbook. Install swing set where a child can easily be supervised. Do not install playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are generally not adequate protective surfacing. Install your play equipment on level ground with adequate surfacing and anchoring. Use proper hardware, and tighten all connections.

Lay out all the pipes and end frame fittings on the ground about two feet from where you have determined you want to place your swing set. Do not dig holes until frame is assembled, as there may be some variance in leg spacing. Slide the two end frame fittings on each end of the top pole with the two legs of the end frame fittings, pointing down. You may have to force pipes into end pipe openings. Tighten the two included set screws on the top of each of the end frame fitting, using the 6mm Allen wrench. Attach swing hangers. The hangers should be spaced 2 ft. from the end of the set and 2 ft. apart. Place the two halves of the hanger around the top rail of the swing set. The swinging shackle pendulum will be facing downwards. The side bolts are placed with the heads on the top of the hanger and the threads facing downwards with the nuts on the bottom. Using a ratchet socket wrench and with no more than 50 lbs. of torque, tighten the side bolts. After tightening, the threads should not be showing more than two threads past the nut, and the hanger should fit snugly on the pipe. Grease or oil bushings if squeaking noises are heard. Use the A5750 to open shackle bolt on the bottom of the shackle pendulum. Slide chain on the bolt and then tighten in the hanger until snug. You may have to force bolt through coating on chain. Close according to Figure A1.19 for Fastening Devices. You can now attach swing to the bottom of the chain with shackles. The swing is intended for children from four to twelve years old. Warning on swing seat should face upward. This swing is intended for use by only one child at a time. Measure each side of swing chain before attaching to make sure that the swing will hang evenly. Attach the bottom of each chain to the large metal triangle on swing seat with a shackle. The bolt on shackle goes through the chain with "C" part of shackle going through triangular hardware on swing seat. Use the A5750 to open shackle bolt. Slide the shackle onto the swing hardware, and then slide the bolt through the bottom of the chain. Tighten the bolt into the shackle until snug. You may have to force bolt through coating on chain. Close according to Figure A1.19 for Fastening Devices.

After attaching swing to the chain, slide the frame leg poles into each leg of the end frame fitting and tighten the included set screws for each leg. The set screws use a 6 millimeter Allen wrench. Make sure set screws are tight. Make sure that pipes are all far enough in frame fittings holes to stabilize frame. After frame is all assembled, have multiple people lift structure and rotate structure, so that it is upright. Measure distances between legs, then, drive stakes into the ground at the correct distances for each pipe at the location of the swing set as you have determined above. Dig holes until you have the correct number of holes. Dig holes that are two feet deep and two feet in diameter. Place a brick in the bottom of each hole with the widest edge facing up. The bricks will prevent the swing set from sinking in the dirt. Set the swing set in place. Lift the set and **do not drag**. Make sure there is at least four inches of space around the entire end of pipe, so that concrete will surround the pipe. Hold a level on the top bar of the swing set. Add gravel under each brick to adjust the height as needed. Pour the contents of two 80-lb. bag of concrete into the wheelbarrow. Add the recommended amount of water to the concrete, and mix with the shovel until there is no dry material. Shovel the mixed concrete into a hole. Smooth the concrete with a trowel. Add dirt if necessary to fill hole, leaving enough space for surfacing. Repeat this step for each hole. Allow the concrete to dry for twenty-four hours, and check for sturdiness before allowing children to use swing set. Try swinging seat without child in it first to make sure everything is working correctly before placing child in seat.

Before allowing children to use set, install adequate surfacing under swing sets to prevent injury from falls. Protective surfacing that meets ASTM F1292 must be installed under swing set and extends at least six feet from the sides of the set and twice the height of the top bar in the front and back of swing set. **Protective surfacing is one of the most important things that you can do to reduce the likelihood of serious injuries.**

The new CPSC standard states the owner/operator of the swing set needs to post warning signs outside the use zone that are readily visible to the intended viewer and alert them to the potential hazard in time to take appropriate action. This message may be on either a sign or label outside the use zone. . Signs should be posted that state the appropriate age group for the swing set. **Not for Adults. Adults should supervise children at all times. Do not allow children to stand on or use unsafely. Do not allow set to be used if damaged. Remove helmets, drawstrings or accessories around the neck which are all known to create head entrapment or entanglement hazards. Where applicable, hot play surfaces are known to reach temperatures high enough to cause serious burns to children generally less than 4 years of age.**

Specifications for all warning signs or labels should conform to ANSI Z535.1 and ANSI Z535.1 or ANSI Z535.1 in the following areas: legibility, type of lettering, clarity of message and symbol, color specifications and work message and visibility. The labels or signs should be durable and conform to UL 969. It has been and continues to be the responsibility of the owner/operator to replace signs or labels or both should they become illegible, destroyed or removed. Signs can be purchased at <http://www.mindspring.com/~safetyplay/>

Safe Use: This seat is for children 4 – 12 years old only. Not for Adults. Adults should supervise children at all times. Do not allow children to stand or kneel on seat or use unsafely. Do not allow swing to be used if damaged. Do not use if wet. Instruct children not to wrap chains around top beam or twist chains. Tell children to watch for children and adults standing, walking or running close to moving swings and to stop swinging to avoid hitting them and causing injury. Tell children to hold chains tightly in each hand while swinging. Tell children not to get off swing until it has stopped completely.

Maintenance: At beginning and end of each play season and once a month during play season, check for sharp edges on hardware and/or cracks in swings or other accessories. Check that set screws are tight on frame fittings. Check that frame is sturdy and does not rock from side to side or rock to or fro. Make sure concrete is still secure and that footing surface is not a tripping hazard. Check for rusty or worn chain. Check to make sure shackles are closed properly. Check to see if oil lite bearing in swing hanger pendulum is worn or cracking. When worn or cracked, replace pendulum. Check to make sure all lock nuts are tight. Check that screws are secure. Check for rust. Take a wire brush or piece of steel wool and

scrub rust from metal surfaces. Please, check for vandalism. Replace parts if necessary. Check resilient surfacing for appropriate depth and cleanliness. Maintaining adequate surfacing is extremely important in reducing injuries. Maintain detailed inspection and maintenance records for public-use playground equipment.

Any damage from vandalism, abuse or misuse VOIDS all warranties.

SKU#S61C

