

531-604 Wall Mounted Basketball Backstop
4 Foot Extension/Aluminum Backboard

Page 2 of 2
Rev. 04/09/03

TOOLS REQUIRED FOR INSTALLATION:

1	Tape Measure	1	Level
1	Crescent Wrench	1	9/16" Socket Wrench

ASSEMBLY AND INSTALLATION:

NOTE: All threaded ends of bolts protruding beyond nuts must be cut off and/or peened to eliminate sharp edges. No more than two threads should extend beyond face of nut.
All washers, "T" nuts, and other fastener hardware used on round pipe or tubing must be hammered down to conform to the curved underlying surface to eliminate catch points.
Mounting board is 2 x 10 pine.

STEP #1: Attach 533-253 & 533-254 Braces to 533-230 Mounting Boards using:

2 - 3/8" x 2 1/2" Elevator Bolts
2 - 3/8" Flat Washers
2 - 3/8" Hex Nuts

STEP #2: Attach 533-234 Support to 533-228 Mounting Board using:

4 - 3/8" x 2 1/2" Elevator Bolts
4 - 3/8" Flat Washers
4 - 3/8" Hex Nuts

STEP #3: Attach mounting boards to wall.

NOTE: Because of varied mounting surfaces (brick, siding, etc.) fasteners to secure mounting boards to wall are NOT provided

STEP #4: Attach 533-253, 533-254, 543-202 & 603-207 Braces to 533-234 Support using:

8 - 3 1/2" Pipe Clamps
8 - 3/8" x 1 1/2" Hex Bolts
4 - 3/8" Flat Washers
8 - 3/8" Hex Nuts

STEP #5: Attach 533-217 Goal and Net to 543-008 Aluminum Backboard and 533-242 Support using:

4 - 3/8" x 1 1/2" Hex Bolts
4 - 3/8" Flat Washers
4 - 3/8" Hex Nuts

STEP #6: Attach 603-207 and 543-202 Braces to 543-008 Aluminum Backboard using:

2 - 3/8" x 1" Hex Bolts

NOTE The official height of a goal and net is 10 feet from floor to top of rim