# 562-605 LaCrosse Goal - Portable

Page 1 Rev 08/10/2004

## IMPORTANT

PLEASE READ THESE INSTRUCTIONS BEFORE COMMENCING ASSEMBLY. All equipment must be installed in accordance with these instructions. Check your shipment against Bill of Lading and Parts list. Any missing or broken parts must be reported to your distributor within 10 days of receipt of your order. When properly installed and maintained, equipment will give many years of Safe, Trouble-Free use. Periodically check for loose or broken parts. Loose bolts must be tightened and broken parts must be replaced as they can possibly create dangerous situations leading to unnecessary accidents.



PACKING LIST						HARDWARE BAG		
1	CTN	1		Hardware Bag	2	126-701	3/8" x 1 ¼" Button Head Bolt	
1	CTN	1	565-932	Nets (pair)	8	196-807	3/8" x 3/8" Socket Set Screw	
2	PIPE	2	563-507	Cross Bar 1 7/8″ OD	2	226-602	3/8" Nylon Insert Lock Nut	
4	PIPE	4	563-505	Upright 1 7/8" OD	4	316-601	3/8" Flat Washer	
4	PIPE	4	536-508	Base Half	1	416-350	3/16" Socket Key	
					1	416-505	7/32" Long Arm Socket Key	
					10	905-517	3/8" x 12" Spike	
					50	905-518	11" Wire Tie	

2 CTN	10 PIPE	12 TOTAL PCS	130 # Weight	Class 70

## SportsPlay Equipment, Inc., 5642 Natural Bridge, St. Louis, MO 63120 (314) 389-4140 www.sportsplayinc.com

# 562-605 LaCrosse Goal - Portable

### GENERAL ASSEMBLY INSTRUCTIONS:

- 1. Check each piece carefully and remove any sharp projections that may have been caused by shipping.
- 2. DO NOT Tighten bolts more than hand tight until entire assembly is completed.
- 3. All Threaded ends of bolts protruding beyond nuts should be cut off and peened over to remove any sharp edge.

### SPECIFIC ASSEMBLY INSTRUCTIONS:

- 1. Assemble goal on ground.
- Connect frame halves using 3/8" x 1 ¼" Button Head Bolts, 3/8" flat washers, and 3/8" Lock Nut. Assemble with nut at BOTTOM of portable frame. Tighten using the 7/32" Socket Key.
- Attach uprights to portable frame halves using 3/8" socket set screws. Only hand-tighten until goal is completely assembled.
- 4. Attach crossbar to uprights using 3/8" socket set screws. Only handtighten until goal has been completely assembled.
- 5. After all posts have been connected and are plumb and level, making sure to maintain the 6' x 6' inner opening of the goal, tighten set screws and bolts using socket keys.
- 6. Position goal and stake down in four places.
- 7. Attach net to frame using wire ties.

### MAINTENANCE INSTRUCTIONS:

Check periodically for loose bolts and/or broken parts and replace immediately.

#### SPECIFICATIONS:

Lacrosse goal shall be fabricated from 1 7/8" 13 gauge galvanized steel, painted orange with an electrostatically applied polyester powder coat finish. Goal dimensions shall be official size: 6' h x 6'w x 7'd. Lacrosse net shall be a 3mm braided, knotless nylon white in color