

Installation steps:

1: Locate the footing position, dig a hole in size 18X18X42"

2: Make concrete base with 5.5" height, and put in-ground kit.

3: Pour concrete again with 32" height.

4: Cover by soil with 4" height.

75-21004 Lotus Spinner

Number	Name	Model	Quantity
1			
2			
3			

