





Model # 950P(SM)-V4

11/5/2019 Page 1 of 9



SAFETY WARNINGS & EQUIPMENT INSPECTION

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severly worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediatly.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
 NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

11/5/2019 Page 2 of 9

HARDWARE



5/16" X 1" Machine Bolt



5/16" Washer




5/16" Kep Nut





800-45-ULTRA www.ultra-site.com


11/5/2019 Page 3 of 9

TOOLS REQUIRED











800-45-ULTRA www.ultra-site.com

11/5/2019 Page 4 of 9

ULTRA SITE PRODUCT SPECIFICATIONS

950P(SM)-V4 SURFACE MOUNT CAPRI BENCH WITH BACK

Seats: Seats dimensions are 25" x 20" x 48". Seats are fabricated 3/4" #9 steel expanded metal. End plates are made of 10 gauge flat steel plate. Reinforced with 3/16 x 1-1/2" flat strip. Electrically MIG welded.

Coating: Oven fused functionalized polyethylene copolymer-based thermoplastic. Fluidized bed coating application with superior mechanical performance, impact resistance and UV-stability.

Frame: Legs are 2-3/8" O.D. x 12 gauge pre-galvanized structural steel tubing. Seat support is bent over a mandrel through the bend radius producing a wrinkle free bend. Tube ends are pre-galvanized steel capped. Seat mounting points are 7 gauge x 1-1/2" die stamped steel flat bar. Cross braces are 1" O.D. x 16 gauge pre-galvanized structural steel tubing. Brace mounting points are 7 gauge x 1-1/2" die stamped steel flat bar. All electrically MIG welded.

Frame Coating: Electrostatic powder coated application oven cured.

Hardware: All stainless steel hardware fasteners.


Dimensions: 4' portable/surface mount bench with back. Seats are 25" wide x 48-1/8" long. Seat height is 18" from the ground to the top of the seat. The overall dimensions are 50" x 26-1/2" x 34"



800-45-ULTRA www.ultra-site.com

11/5/2019 Page 5 of 9

COMPONENTS



Optional Surface Mount Hardware: 3/8" x 3-1/2" Concrete Expansion Anchor Bolts (Not Included)


ITEM NO.	PartNo	DESCRIPTION	QTY
1	T-V48CP-S	4' expanded capri seat	1
2	P-V950SM-R	950 SM Leg-RH	1
3	P-V950SM-L	950 SM leg-LH	1
4	01-01-0093	950 armrest	2
5	P-01-01-0092	22 11/16" Brace	2
6	33-02-0007	5/16" SS Washer	20
7	33-05-0029	5/16" x 1" Machine Bolt (SS)	10
8	33-03-0012	5/16" Kep Nut (SS)	10

ultra site.

800-45-ULTRA www.ultra-site.com

11/5/2019 Page 6 of 9

STEP 1




Attach the 950 Armrest to the 4' Seat while attaching the seat to the 950 Legs using specified hardware.



800-45-ULTRA www.ultra-site.com

11/5/2019 Page 7 of 9

STEP 2




Attach the 22 11/16" Brace to the seat and legs using specified hardware.



800-45-ULTRA www.ultra-site.com

11/5/2019 Page 8 of 9



11/5/2019 Page 9 of 9