

Super Slide Installation

Insert four (4) slide legs (red poles) into bottom of slide platform, secure with bolts provided (requires $\frac{3}{4}$ " wrench). Stand unit up, dig four holes approximately 12" deep beside each slide leg. Lower the unit into the holes. Dig two holes for the bottom of ladder, 1 foot deep, install ladder by removing 1 pipe plug and placing rod thru top of ladder. The deck height should be five feet from ground surfacing. Center the slide on the mounting bracket, using holes in mounting bracket. Mark locations on the slide with a marker. Drill with a $\frac{1}{2}$ " drill bit through the first layer of plastic. Insert snap toggles in holes, place slide back on mounting bracket and attach using screws and washers. Fill holes with concrete for each slide leg and ladder.

