

Sit-N-Spin Install

STEP: 1

The Sit-N-Spin requires you to dig a hole that is 18" wide x 18" deep. Once you dig the proper hole, insert the climber and cement into place. Refer to General Installation guide for further information.

