

This set is very heavy duty. Each bay is designed for two children up to 12 years old, per ASTM and CPSC guidelines. If installed according to installation instructions, our sets will more than meet these requirements.

Actual weight limits depend upon how the set is installed, the amount of concrete, the type of dirt in which the set is installed, how much use, etc. Therefore, we do not state weight limits for our swing sets.

This frame is for an in ground 3 bay heavy duty 10' high set. You will need to specify colors for the End Frame Fittings, Middle Frame Fittings, Swing Chain and the Commercial Swing Seats. This product should last 2 years in harsh conditions and up to 5 years in optimal conditions. Some conditions may require replacement sooner.

TOOLS AND PARTS NEEDED:

Ladder, ¾" wrench, Ratchet socket wrench, Tape measure, supplied Allen wrench for shackles, and 6mm Allen wrench for set screws, Stakes for marking holes, Shovel, Bricks, Gravel, Wheelbarrow for mixing concrete, Water, Concrete, Trowel, Level, Warning signs. Protective surfacing according to ASTM F1292 for a fall height of 10'.

MEASUREMENTS FOR SWING FRAME:

The Front (A) and Back (B) legs are 110" apart above ground and 128" below ground. Lengthwise, the two front legs (A) to (A) are 376" apart. The two middle legs (AA), which are the legs furthest apart, are 460" apart. The front leg (A) to the middle leg (AA) is 72.5" apart above ground. The front leg (A) to the middle front leg (C) is 126" apart. The height of the set is 10'.

****INSTALLATION, SAFE USE & MAINTENANCE INSTRUCTIONS****

IMPORTANT: To keep children safe from harm, follow these precautions and instructions when installing, using, or maintaining this playground equipment. You can also call us at 1-800-433-2573 for more information or see <http://www.cpsc.gov/cpscpub/pubs/324.pdf>.

Installation: Read all instructions before attempting assembly. To determine proper use zones needed for swing set consult Figure 23, Table 7 for commercial swing sets. For residential sets see spacing dimensions on Page 4 of the Outdoor Home Playground Safety Handbook. Install swing set where a child can easily be supervised. Do not install playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are generally not adequate protective surfacing. Install your play equipment on level ground with adequate surfacing and anchoring. Use proper hardware, and tighten all connections.

Lay out all the pipes and end frame fittings on the ground about two feet from where you have determined you want to place your swing set. Do not dig holes until frame is assembled, as there may be some variance in leg spacing. Lay an end frame fitting on one end, then a top beam, then a middle frame fitting, then a top beam, then a middle frame fitting, then a top beam, and finally the remaining end frame fitting.

Slide the two end frame fittings on one end of each of the two 10' top poles with the three legs of the end frame fittings, pointing down. You may have to force pipes into end pipe openings. Tighten the two included set screws on the top of each of the end frame fitting, using the 6mm Allen wrench. Attach four swing hangers, with two hangers for each top beam. The hangers should be spaced 2 ft from the end of the set and 2 ft apart. Place the two halves of the hanger around the top rail of the swing set. The swinging shackle pendulum will be facing downwards. The side bolts are placed with the heads on the top of the hanger and the threads facing downwards with the nuts on the bottom. Using a ratchet socket wrench and with no more than 50 lbs. of torque, tighten the side bolts. After tightening, the threads should not be showing more than two threads past the nut, and the hanger should fit snugly on the pipe. Grease or oil bushings if squeaking noises are heard. Use the A5750 to open shackle bolt on the bottom of the shackle pendulum. Slide chain on the bolt and then tighten in the hanger until snug. You may have to force bolt through coating on chain. Close according to Figure A1.19 for Fastening Devices.

You can now attach swing to the bottom of the chain with shackles. The swing is intended for children from four to twelve years old. Warning on swing seat should face upward. This swing is intended for use by only one child at a time. Measure each side of swing chain before attaching to make sure that the swing will hang evenly. Attach the bottom of each chain to the large metal triangle on swing seat with a shackle. The bolt on shackle goes through the chain with "C" part of shackle going through triangular hardware on swing seat. Use the A5750 to open shackle bolt. Slide the shackle onto the swing hardware, and then slide the bolt through the bottom of the chain. Tighten the bolt into the shackle until snug. You may have to force bolt through coating on chain. Close according to Figure A1.19 for Fastening Devices.

Now take one Middle Frame Fitting and attach one end to the other side of the first top beam attached to the first of the end frame fittings. You may have to force pipes into end pipe openings. Attach second top beam into the Middle Frame Fitting's other top hole. Tighten the included set screws on the top of the middle frame fitting, using the 6mm Allen wrench. Attach the final four swing hangers to the top beam. The hangers should be spaced 2 ft from the end of the set and 2 ft apart. Place the two halves of the hanger around the top rail of the swing set. The swinging shackle pendulum will be facing downwards. The side bolts are placed with the heads on the top of the hanger and the threads facing downwards with the nuts on the bottom. Using a ratchet socket wrench and with no more than 50 lbs. of torque, tighten the side bolts. After tightening, the threads should not be showing more than two threads past the nut, and the hanger should fit snugly on the pipe. Grease or oil bushings if squeaking noises are heard. Use the A5750 to open shackle bolt on the bottom of the shackle pendulum. Slide chain on the bolt and then tighten in the hanger until snug. You may have to force bolt through coating on chain. Close according to Figure A1.19 for Fastening Devices.

You can now attach swing to the bottom of the chain with shackles. The swing is intended for children from four to twelve years old. Warning on swing seat should face upward. This swing is intended for use by only one child at a time. Measure each side of swing chain before attaching to make sure that the swing will hang evenly. Attach the bottom of each chain to the large metal triangle on swing seat with a shackle. The bolt on shackle goes through the chain with "C" part of shackle going through triangular hardware on swing seat. Use the A5750 to open shackle bolt. Slide the shackle onto the swing hardware, and then slide the bolt through the bottom of the chain. Tighten the bolt into the shackle until snug. You may have to force bolt through coating on chain. Close according to Figure A1.19 for Fastening Devices.

Now take the second Middle Frame Fitting and attach one end to the other side of the top beam attached to first of the middle frame fittings, and one end to the top beam attached to the second end frame fitting. Swings should already be attached to this top beam. You may have to force pipes into end pipe openings. Tighten the included set screws on the top of the middle frame fitting, using the 6mm Allen wrench. **Make sure set screws are tight.**

Now, it is time to attach the legs. Slide the longer front and back frame leg poles, 152", into each leg of the end frame fitting and tighten the included set screws for each leg. The set screws use a 6 millimeter Allen wrench. Make sure set screws are tight. Then, using the same procedure, slide the shorter middle legs, 150", into the end frame fitting. Tighten the included set screws for each leg. Make sure set screws are tight. Next insert the four pipes, 152", into the leg openings for the Middle Frame Fittings. Using the included set screw, tighten with a 6 mm Allen wrench. Make sure the set screws are tight. Make sure that pipes are all far enough in frame fittings holes to stabilize frame. After frame is all assembled, have multiple people lift structure and rotate structure, so that it is upright.

Measure distances between legs, then, drive stakes into the ground at the correct distances for each pipe at the location of the swing set as you have determined above. Dig holes until you have the correct number of holes. Dig holes that are two feet deep and two feet in diameter.

Place a brick in the bottom of each hole with the widest edge facing up. The bricks will prevent the swing set from sinking in the dirt. Set the swing set in place. Lift the set and **do not drag**. Make sure there is at least four inches of space around the entire end of pipe, so that concrete will surround the pipe. Hold a level on the top bar of the swing set. Add gravel under each brick to adjust the height as needed.

Pour the contents of two 80-lb. bag of concrete into the wheelbarrow. Add the recommended amount of water to the concrete, and mix with the shovel until there is no dry material. Shovel the mixed concrete into a hole. Smooth the concrete with a trowel. Add dirt if necessary to fill hole, leaving enough space for surfacing. Repeat this step for each hole. Allow the concrete to dry for twenty-four hours, and check for sturdiness before allowing children to use swing set. Try swinging seat without child in it first to make sure everything is working correctly before placing child in seat.

Before allowing children to use set, install adequate surfacing under swing sets to prevent injury from falls. Protective surfacing that meets ASTM F1292 must be installed under swing set and extends at least six feet from the sides of the set and twice the height of the top bar in the front and back of swing set. **Protective surfacing is one of the most important things that you can do to reduce the likelihood of serious injuries.**

The new CPSC standard states the owner/operator of the swing set needs to post warning signs outside the use zone that are readily visible to the intended viewer and alert them to the potential hazard in time to take appropriate action. This message may be on either a sign or label outside the use zone. Signs should be posted that state the appropriate age group for the swing set. **Not for Adults. Adults should supervise children at all times. Do not allow children to stand on or use unsafely. Do not allow set to be used if damaged. Remove helmets, drawstrings or accessories around the neck which are all known to create head entrapment or entanglement hazards. Where applicable, Hot play surfaces are known to reach temperatures high enough to cause serious burns to children generally less than 4 years of age.**

Specifications for all warning signs or labels should conform to ANSI Z535.1 and ANSI Z535.1 or ANSI Z535.1 in the following areas: legibility, type of lettering, clarity of message and symbol, color specifications and work message and visibility. The labels or signs should be durable and conform to UL 969. It has been and continues to be the responsibility of the owner/operator to replace signs or labels or both should they become illegible, destroyed or removed. Signs can be purchased at <http://www.mindspring.com/~safetyply/>

Safe Use: This seat is for children 4-12 years old only. Not for Adults. Adults should supervise children at all times. Do not allow children to stand or kneel on seat or use unsafely. Do not allow swing to be used if damaged. Do not use if wet. Instruct children not to wrap chains around top beam or twist chains. Tell children to watch for children and adults standing, walking or running close to moving swings and to stop swinging to avoid hitting them and causing injury. Tell children to hold chains tightly in each hand while swinging. Tell children not to get off swing until it has stopped completely.

Maintenance: At beginning and end of each play season and once a month during play season, check for sharp edges on hardware and/or cracks in swings or other accessories. Check that set screws are tight on frame fittings. Check that frame is sturdy and does not rock from side to side or rock to or fro. Make sure concrete is still secure and that footing surface is not a tripping hazard. Check for rusty or worn chain. Check to make sure shackles are closed properly. Check to see if oil lite bearing in swing hanger pendulum is worn or cracking. When worn or cracked, replace pendulum. Check to make sure all lock nuts are tight. Check that screws are secure. Check for rust. **Take a wire brush or piece of steel wool and scrub rust from metal surfaces.** Please, check for vandalism. **Replace parts if necessary.** Check resilient surfacing for appropriate depth and cleanliness. Maintaining adequate surfacing is extremely important in reducing injuries. Maintain detailed inspection and maintenance records for public-use playground equipment.

Any damage from vandalism, abuse or misuse VOIDS all warranties.

BASIC POLICY & PROVISIONS

Playset's are shipped via Curbside Shipping. Delivery will be done by a tractor/trailer (a semi truck). The driver is only responsible for delivering (driving) the order to your curb. A delivery appointment is scheduled by the freight company via the phone number (s) you provide in your order. No delivery will be made unless an appointment is set. The delivery person requires your assistance in unloading the order. Any additional services, such as two-man delivery or inside delivery are not included in the price of the freighted item. The cost of these additional services varies from city to city. They usually cost between \$50.00 and \$150.00 extra. You may purchase the additional services directly from the freight carrier when delivery is scheduled. It is a good idea when you make your appointment, to have the freight company call you 30 to 45 minutes before delivery so as to avoid having to wait for the driver to show up.

RECEIPT OF SHIPMENT/CUSTOMER RESPONSIBILITY

Before signing for you order, check to see that you are receiving the same number of cartons, bundles, and loose pieces etc., indicated on your receipt. Note any shortages or visible damage on your receipt and have the driver note these also.

Damage which is found after you unpack the shipment (concealed damage) must be reported to Customer Service immediately. Please closely inspect your shipment! Most freight companies allow 10 days from receipt to report concealed damage.

NOTE: If you discover damage of any kind, DO NOT DESTROY ANY ORIGINAL SHIPPING CARTONS.

LOSS OR DAMAGE IN SHIPMENT

Customer signing bill of lading at time of delivery is our receipt from the carrier. We therefore, are released of all responsibility for loss or damage in transit. Merchandise, as received by you, should be carefully checked against the freight bill to be sure delivery of all items has been made.

Count the shipment and inspect for damage. If shipment is not delivered to you in good order and in accordance with the quantity shown on the Freight Bill of Lading, please note the shortage or damage on the Freight Bill before you sign for the shipment. Please contact your sales representative to advise the company of the shortage or damage.

As soon as possible after delivery, open all cartons and inspect for concealed damage. If you do have shortages or damage in cartons, please contact your representative's office immediately so replacements can be made.

Do not throw away your copy of the Freight Bill. Any damaged or missing pieces not signed for as such on the Freight Bill of Lading will be replaced at the replacement cost, and freight charges will be charged to deliver the merchandise to your site.

Please note that the driver is obligated to bring your merchandise to the end of the trailer. It may then be advisable to have someone on hand to assist in unloading the merchandise as these systems come on 8' to 12' long pallets and weigh a minimum of 500 pounds.

SKU#H106

