





# IMBARIMBA INSTALLATION GUIDE



## Main Features:

- (LH) C Major / (RH) A Minor Pentatonic
- Recycled HDPE Frame
- Coated Fiberglass Bars
- Anodized Aluminum Resonators
- Stainless Steel Hardware

## Contents:

- SHEET 2 - Parts List and Instrument to Post Installation
- SHEET 3 - In Ground Installation
- SHEET 4 - Surface Mount Installation

## Weights:

- Instrument Weight, 49lbs.
- Boxed Instrument Weight, 60lbs.
- Boxed Posts Weight, 35-72lbs.

TITLE:  
Imbarimba - Installation Guide

DWG. NO. IMBA-INSTALL

REVISION: B

SCALE: 1:16

DATE: 3/21/2018


SHEET 1 OF 4

**Parts List:**

ITEM NO.	PART DESCRIPTION	In Ground - Recycled Post/QTY.	In Ground - Steel Post/QTY.	Surface Mount Recycled Post/QTY.	Surface Mount Steel Post/QTY.
1	Imbarimba Instrument Assembly	1	1	1	1
2	Small SS Holster	2	2	2	2
3	In Ground Recycled Post, 72"lg.	2	-	-	-
4	In Ground Steel Post, 72"lg.	-	2	-	-
5	Surface Mount Recycled Post, 36"lg.	-	-	2	-
6	Surface Mount Steel Post, 36"lg.	-	-	-	2
7	Surface Mount Base, For Recycled Post	-	-	2	-
8	#8 Flat Head Screw, .5"lg. SS, T15 tamp	8	8	8	8
9	#8 Button Head Screw, 1.25"lg. SS, T15 tamp	10	-	10	-
10	#10-24 Button Head Machine Screw, 1"lg. SS, T25 tamp	-	10	-	10
11	5/16" Hex Head Lag Bolt, 5"lg. SS	-	-	4	-
12	3/8"-16 Wedge Expansion Anchor, SS	-	-	8	8
13	35/64" Hex Nut Cap	-	-	8	8
14	Security Driver	1	2	1	2

**Step 1:** Start by mounting the Holsters to the Instrument Back with the provided #8 Flat Head Screws and Driver. The Back comes predrilled. Screw heads should be flush with the Holster surface when properly installed. Holster should also be flush along the back. Drive Screws slowly to prevent stripping.

**Step 2:** With two people, situate the Instrument with Holsters installed onto the Posts. Posts come predrilled and/or tapped. Fasten the Instrument to the Posts with the provided #8 Button Head Screw for Recycled Posts or #10-24 Button Head Machine Screw for Steel Posts. Drivers are provided.



**DETAIL B**  
SCALE 1 : 4

**DETAIL A**  
SCALE 1 : 4


**Step 1:** Excavate two 10" diameter holes, 36" deep, and 30" on center at the installation location. Contractor can modify Post to desired height. **Post Length = Frost Depth (36" Recommended) + Finished Post Height**

**Finished Post Height Guideline:** (Ages 3-5, 22") (Ages 5-7, 27") (Ages 7-11, 32") (Adult, 36")

**Step 2:** With two people, lower the Posts with the Instrument attached into the excavated holes.

**Step 3:** Verify the correct placement, levelness, and finished height of the Instrument. Check for sufficient clearance around the Instrument, a 36" perimeter around the Instrument is recommended for wheelchair accessibility.

**Step 4:** Last pour concrete around the posts. It is recommended to brace the Instrument to hold it rigid while the concrete cures. Leave to set according to the concrete manufacturers guidelines. Approximately (6) 80lb. bags will be needed.



TITLE:  
**In Ground Installation**

DWG. NO. **IMBA-INSTALL**

REVISION: B

SCALE: 1:16

DATE: 3/21/2018

SHEET 3 OF 4

**Step 1:** Standard height for Surface Mount Posts are 36". The Recycled Posts may be modified in the field to the following heights:  
 (Ages 3-5, 22") (Ages 5-7, 27") (Ages 7-11, 32") (Adult, 36")  
 The height of Surface Mount Steel Posts can not be adjusted.

**Step 2:** Determine installation location. Verify concrete footing is a minimum of 48" long x 24" wide x 6" thick. If the concrete pad is at an angle, steel washers are required to act as shims (Shims not provided). If there is not already an existing pad, approximately (7) 80lb. bags will be needed. Allow concrete to cure per concrete manufacturers guidelines.


**Step 3 (Recycled Post Only):** Install the Surface Mount Bases to the bottom of the Posts. Align the holes on the Bases with the holes on the Posts. The Bases should fit snugly around the Posts. Fasten them together with the provided 5/16" Hex Head Lag Bolts.

**Step 4:** With two people place the Instrument Assembly with Posts attached onto the concrete pad and mark the center of the holes on the surface mount bases. After you have made your marks, set aside the Instrument in order to drill for anchor holes. With a hammer or rotary drill, drill through concrete at marked locations. Drill to a minimum depth of 4". A 3/8" masonry drill bit will be needed.




**Step 5:** Place the Instrument back over the drilled out holes. Insert provided anchor bolts into aligned holes. Position anchor nut so that it is flush with the top of the bolt. Pound anchor bolts into the hole until the anchor washer is flush with the surface mount bases. Tighten anchor bolts until they are snug. Cover remaining bolt sections with provided nut caps.

**Step 6:** Verify the correct placement, levelness, and finished height of the Instrument. Check for sufficient clearance around the Instrument, a 36" perimeter around the Instrument is recommended for wheelchair accessibility.


**Step 7:** If installing onto wet concrete, us the wet set anchor manufacturers guidelines for installation procedures.



# SWIRL INSTALLATION GUIDE



80" Adult  
71" Ages 7-11  
63" Ages 5-7  
59" Ages 3-5



### Main Features:

- (LH) C Major / (RH) A Minor Pentatonic
- Recycled HDPE Frame
- Anodized Aluminum Chimes & Resonators
- Stainless Steel Hardware

### Contents:

- SHEET 2 - Parts List and Instrument to Post Installation
- SHEET 3 - In Ground Installation
- SHEET 4 - Surface Mount Installation

### Weights:

- Instrument Weight, 197lbs.
- Boxed Instrument Weight, 215lbs.
- Boxed Posts Weight, 65-87lbs.

**Parts List:**



FREENOTES HARMONY PARK  
 544 CHESTNUT ST.  
 CHATTANOOGA, TN 37402  
 TEL: 833.262.1569


WWW.FREENOTESHARMONYPARK.COM

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS  
 DRAWING IS THE SOLE PROPERTY OF  
 FREENOTES HARMONY PARK. ANY  
 REPRODUCTION IN PART OR AS A  
 WHOLE WITHOUT THE WRITTEN  
 PERMISSION OF FREENOTES HARMONY  
 PARK IS PROHIBITED.

ITEM NO.	PART DESCRIPTION	In Ground - Recycled Post/QTY.	In Ground - Steel Post/QTY.	Surface Mount - Steel Post/QTY.
1	Swirl Instrument Assembly	1	1	1
2	Large SS Holster	2	2	2
3	In Ground Recycled Post, 96"lg.	2	-	-
4	In Ground Steel Post, 96"lg.	-	2	-
6	Surface Mount Steel Post, 60"lg.	-	-	2
6	#8 Flat Head Screw, .5"lg. SS, T15 tamp	12	12	12
8	#8 Button Head Screw, 1.25"lg. SS, T15 tamp	12	-	-
9	#10-24 Button Head Machine Screw, 1"lg. SS, T25 tamp	-	12	12
9	3/8"-16 Wedge Expansion Anchor, 3.75"lg. SS	-	-	8
10	35/64" Hex Nut Cap	-	-	8
11	Security Driver	1	1	1

**Step 1:** Start by mounting the Holsters to the Instrument Back with the provided #8 Flat Head Screws and Driver. The Back comes predrilled. Screw heads should be flush with the Holster surface when properly installed. Holster should also be flush along the back. Drive Screws slowly to prevent stripping.

**Step 2:** With two people, situate the Instrument with Holsters installed onto the Posts. Posts come predrilled and/or tapped. Fasten the Instrument to the Posts with the provided #8 Button Head Screw for Recycled Posts or #10-24 Button Head Machine Screw for Steel Posts. Drivers are provided.



TITLE:  
**Parts List and Instrument to Post Installation**

DWG. NO. **SWRL-INSTALL**

REVISION: B  
 SCALE: 1:16  
 DATE: 3/23/2018  
 SHEET 2 OF 4


**Step 1:** Excavate two 10" diameter holes, 36" deep, and 32" on center at the installation location. Contractor can modify Post to desired height. **Post Length = Frost Depth (36" Recommended) + Finished Post Height**

**Finished Post Height Guideline:** (Ages 3-5, 39") (Ages 5-7, 43") (Ages 7-11, 51") (Adult, 60")

**Step 2:** With two people, lower the Posts with the Instrument attached into the excavated holes.

**Step 3:** Verify the correct placement, levelness, and finished height of the Instrument. Check for sufficient clearance around the Instrument, a 36" perimeter around the Instrument is recommended for wheelchair accessibility.

**Step 4:** Last pour concrete around the posts. It is recommended to brace the Instrument to hold it rigid while the concrete cures. Leave to set according to the concrete manufacturers guidelines. Approximately (6) 80lb. bags will be needed.



TITLE:  
**In Ground Installation**

DWG. NO. SWRL-INSTALL

REVISION: B

SCALE: 1:16

DATE: 3/23/2018

SHEET 3 OF 4



**Step 1:** Standard height for Surface Mount Posts are 60". **The height of Surface Mount Steel Posts can not be adjusted.**


**Step 2:** Determine installation location. Verify concrete footing is a minimum of 48" long x 30" wide x 6" thick. If the concrete pad is at an angle, steel washers are required to act as shims (Shims not provided). If there is not already an existing pad, approximately (9) 80lb. bags will be needed. Allow concrete to cure per concrete manufacturers guidelines.

**Step 3:** With two people place the Instrument Assembly with Posts attached onto the concrete pad and mark the center of the holes on the surface mount bases. After you have made your marks, set aside the Instrument in order to drill for anchor holes. With a hammer or rotary drill, drill through concrete at marked locations. Drill to a minimum depth of 4". A 3/8" masonry drill bit will be needed.

**Step 4:** Place the Instrument back over the drilled out holes. Insert provided anchor bolts into aligned holes. Position anchor nut so that it is flush with the top of the bolt. Pound anchor bolts into the hole until the anchor washer is flush with the surface mount bases. Tighten anchor bolts until they are snug. Cover remaining bolt sections with provided nut caps.



**Step 5:** Verify the correct placement, levelness, and finished height of the Instrument. Check for sufficient clearance around the Instrument, a 36" perimeter around the Instrument is recommended for wheelchair accessibility.

**Step 6:** If installing onto wet concrete, us the wet set anchor manufacturers guidelines for installation procedures.





# TUNED DRUMS INSTALLATION GUIDE



### Main Features:

- Low to High Tuning
- Cap Color Options


### Contents:

- SHEET 2 - In Ground Installation w/ Parts List
- SHEET 3 - Surface Mount Installation w/ Parts List

### Weights:

- Instrument Total Weight, 60-84lbs.
- Boxed Instrument Total Weight, 90-110lbs.
- Individual Drum Weights vary per style and finished height selection

### Cap Color Options:



TITLE:

Tuned Drums - Installation Guide

DWG. NO. TD-INSTALL

REVISION: NA

SCALE: 1:16

DATE: 2/9/2018

SHEET 1 OF 3

**Parts List:**

ITEM NO.	DESCRIPTION	QTY.	NORMAL FINISHED HEIGHT	TODDLER FINISHED HEIGHT
1	Ø 15" In Ground Tuned Drum	1	37"	29"
2	Ø 12" In Ground Tuned Drum	1	35"	27.5"
3	Ø 10" In Ground Tuned Drum	1	33"	26"
4	Ø 8" In Ground Tuned Drum	1	31"	24.5"
5	Ø 6" In Ground Tuned Drum	1	29"	23"

**Step 1:** Arrange Drums in desired location and pattern. Drums can be laid out in any configuration desirable, but must be installed less than 3" or greater than 9" apart. **WARNING: Between 3" and 9" there lies a chance for a child's head to get stuck.**  
(Reference: US Consumer Product Safety Commission, Public Playground Safety Handbook)


**Step 2:** Determine border of trench for concrete pad. Trench should be a minimum of 6" deep. Concrete pad should perform under local soil and weather conditions.

**Step 3:** Excavate trench to required depth. Check levelness of trench then pour concrete and fill trench completely per code requirements. Immediately after the concrete has been poured, drive the Tuned Drums into the wet concrete per your chosen layout.

**Step 4:** The bottom edge of the Drum Bases are scalloped to assist in their installation into the concrete. Twist Drums into concrete to a depth of 5". Check for plumbness, if needed brace the Drums to keep them rigid and in place during the curing process. Leave to set according to the concretemanufacturer's guidelines.

**Step 5:** Check for sufficient clearance around instruments. A 36" clearance is recommended around the the entire Drum arrangement for wheelchair accessibility, however this is not required for proper function. Drums may also be installed next to a wall or in a variety of different configurations.

**Step 6:** Remove plastic film from drum caps if applicable.



Parts List:				
ITEM NO.	DESCRIPTION	QTY.	NORMAL FINISHED HEIGHT	TODDLER FINISHED HEIGHT
1	Ø 15" Surface Mount Tuned Drum	1	37"	29"
2	Ø 12" Surface Mount Tuned Drum	1	35"	27.5"
3	Ø 10" Surface Mount Tuned Drum	1	33"	26"
4	Ø 8" Surface Mount Tuned Drum	1	31"	24.5"
5	Ø 6" Surface Mount Tuned Drum	1	29"	23"
6	Surface Mount Anchor Disc	5	-	-
7	Ø 1/4 x 3.25" Anchor Bolt, SS	15	-	-
8	#10 Button Head Screw, 2"lg. SS, T25 tamp	20	-	-
9	Security Driver	1	-	-

**Step 1:** Arrange Drums in desired location and pattern. Drums can be laid out in any configuration desirable, but must be installed less than 3" or greater than 9" apart.

**WARNING:** Between 3" and 9" there lies a chance for a child's head to get stuck.

(Reference: US Consumer Product Safety Commission, Public Playground Safety Handbook)


**Step 2:** Once you have decided your layout, replace drums with the provided Anchor Discs. Mark holes on the concrete through the (3) holes on all of the Anchor Discs. Set aside Discs, drill 1/4" holes 2" into concrete at marked locations. A Ø 1/4" masonry drill bit will be needed. Contractor to provide a concrete slab that will perform under local soil and weather conditions. (If anchoring to a material other than concrete, fasteners to be provided by the customer)

**Step 3:** Place the Anchor Discs back over the drilled out holes. Insert provided anchor bolts into aligned holes. Position anchor nut so that it is flush with the top of the bolt. Pound anchor bolts into the hole until the anchor washer is flush with the post base. Tighten anchor bolts until they are snug.

**Step 4:** Install the Drums over the Anchor Discs. Predrill (4) 1/8" holes in a 90° cross pattern, 1" up from the bottom of the drum. Drill through both Drum and Anchor Disc. When predrilling holes, make sure they clear the previously installed anchor bolts, and that there is clearance for the 2" screws to be installed without interfering with the other drums. Secure Drums to Discs with the provided #10 Button Head Screws and Driver.

**Step 5:** Check for sufficient clearance around instruments. A 36" clearance is recommended around the the entire Drum arrangement for wheelchair accessibility, however this is not required for proper function. Drums may also be installed next to a wall or in a variety of different configurations.

**Step 6:** Remove plastic film from drum caps if applicable.



FREENOTES HARMONY PARK  
 544 CHESTNUT ST.  
 CHATTANOOGA, TN 37402  
 TEL: 833.262.1569

WWW.FREENOTESHARMONYPARK.COM

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS  
 DRAWING IS THE SOLE PROPERTY OF  
 FREENOTES HARMONY PARK. ANY  
 REPRODUCTION IN PART OR AS A  
 WHOLE WITHOUT THE WRITTEN  
 PERMISSION OF FREENOTES HARMONY  
 PARK IS PROHIBITED.

TITLE: Surface Mount Installation with Parts List

DWG. NO. TD-INSTALL



REVISION: A

SCALE: 1:24

DATE: 2/9/2018

SHEET 3 OF 3

# CONTRABASS CHIMES INSTALLATION GUIDE



### Main Features:

- C Major Pentatonic
- Steel Powder Coated Support Poles
- Anodized Aluminum Chimes
- Stainless Steel Hardware

### Contents:

- SHEET 2 - In Ground Installation w/ Parts List
- SHEET 3 - Surface Mount Installation w/ Parts List

### Weights:

- Instrument Weight, 30-35lbs per chime
- Boxed Instrument Weight, 35-40lbs. per chime
- Mallet Pole Weight, 37lbs.
- Boxed Mallet Pole Weight, 40lbs.

TITLE:  
**Contrabass Chimes - Installation Guide**

DWG. NO. CCH-INSTALL

REVISION: B

SCALE: 1:32

DATE: 1/30/2019

SHEET 1 OF 3

**Parts List:**

ITEM NO.	DESCRIPTION	QTY.
1	Contrabass Chimes - In Ground Chime Assembly 1	1
2	Contrabass Chimes - In Ground Chime Assembly 2	1
3	Contrabass Chimes - In Ground Chime Assembly 3	1
4	Contrabass Chimes - In Ground Chime Assembly 4	1
5	Contrabass Chimes - In Ground Chime Assembly 5	1
6	Contrabass Chimes - In Ground Chime Assembly 6	1
7	Contrabass Chimes - In Ground Chime Assembly 7	1
8	Contrabass Chimes - In Ground Mallet Pole Assembly	2

**Step 1:** Determine your layout. Spacing between Chimes and Mallet Poles must be maintained per the diagram shown to allow the Mallets to reach each Chime. Although the Chimes can be laid out in a variety of styles such as an arc, wave, or straight-line; we suggest one of the following layout orders:

#6, #4, Mallet Pole, #2, #1, #3, Mallet Pole, #5, #7


or

#1, #2, Mallet Pole, #3, #4, #5, Mallet Pole, #6, #7

**Step 2:** After choosing your layout, excavate (9) 10" Diameter holes, at 36" deep.

**Step 3 (Optional):** Pound 18" of 36" long Steel Rebar (not provided) into the center of each hole. This process helps with keeping the Chimes vertical while the concrete cures. Place each Chime and Mallet Pole into their hole over the rebar.

**Step 4:** Place each Chime and Mallet Pole into their hole, then pour concrete around the poles within the holes. Check that everything is level. Leave concrete to set according to the concrete manufacturer's guidelines. If necessary, brace the Chimes to hold them rigid during the curing process. Approximately (27) 80lb. bags will be needed.  
*(Chimes must be as vertical as possible for best sound)*



**Parts List:**

ITEM NO.	DESCRIPTION	QTY.
1	Contrabass Chimes - Surface Mount Chime Assembly 1	1
2	Contrabass Chimes - Surface Mount Chime Assembly 2	1
3	Contrabass Chimes - Surface Mount Chime Assembly 3	1
4	Contrabass Chimes - Surface Mount Chime Assembly 4	1
5	Contrabass Chimes - Surface Mount Chime Assembly 5	1
6	Contrabass Chimes - Surface Mount Chime Assembly 6	1
7	Contrabass Chimes - Surface Mount Chime Assembly 7	1
8	Contrabass Chimes - Surface Mount Mallet Pole, 48" lg.	2
9	3/8"-16 Wedge Expansion Anchor, 3.75"lg. SS	27
10	35/64" Hex Nut Cap	27

**Step 1:** Determine your layout. Spacing between Chimes and Mallet Poles must be maintained per the diagram shown to allow the Mallets to reach each Chime. Although the Chimes can be laid out in a variety of styles such as an arc, wave, or straight-line; we suggest one of the following layout orders:

#6, #4, Mallet Pole, #2, #1, #3, Mallet Pole, #5, #7


or

#1, #2, Mallet Pole, #3, #4, #5, Mallet Pole, #6, #7




**Step 2:** Determine installation location. Verify concrete footing is a minimum of 132" long x 18" wide x 6" thick, depending on the layout you go with. If the concrete pad is at an angle, steel washers are required to act as shims (Shims not provided). If there is not already an existing pad, approximately (23) 80lb. bags will be needed. Allow concrete to cure per concrete manufacturers guidelines.

**Step 3:** With two people place the Chimes and Mallet Poles individually onto the concrete pad and mark the center of the holes on the surface mount plates. After you have made your marks, set aside the Chimes and Mallet poles in order to drill for anchor holes. With a hammer or rotary drill, drill through concrete at marked locations. Drill to a minimum depth of 4". A 3/8" masonry drill bit will be needed.

**Step 4:** Place the Chimes and Mallet Poles back over the drilled out holes. Insert provided anchor bolts into aligned holes. Position anchor nut so that it is flush with the top of the bolt. Pound anchor bolts into the hole until the anchor washer is flush with the surface mount base. Tighten anchor bolts until they are snug. Cover remaining bolt sections with provided nut caps.



# PEGASUS INSTALLATION GUIDE



### Main Features:

- (LH) A Minor / (RH) C Major Pentatonic
- Recycled HDPE Frame
- Anodized Aluminum Bars & Resonators
- Stainless Steel Hardware

### Contents:

- SHEET 2 - Parts List and Instrument to Post Installation
- SHEET 3 - In Ground Installation
- SHEET 4 - Surface Mount Installation

### Weights:

- Instrument Weight, 49lbs.
- Boxed Instrument Weight, 60lbs.
- Boxed Posts Weight, 35-72lbs.

TITLE:  
Pegasus - Installation Guide

DWG. NO. PEG-INSTALL

REVISION: B

SCALE: 1:16

DATE: 3/23/2018

SHEET 1 OF 4



**Parts List:**



FREENOTES HARMONY PARK  
544 CHESTNUT ST.  
CHATTANOOGA, TN 37402  
TEL: 833.262.1569

WWW.FREENOTESHARMONYPARK.COM

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS  
DRAWING IS THE SOLE PROPERTY OF  
FREENOTES HARMONY PARK. ANY  
REPRODUCTION IN PART OR AS A  
WHOLE WITHOUT THE WRITTEN  
PERMISSION OF FREENOTES HARMONY  
PARK IS PROHIBITED.


TITLE:  
**Parts List and Instrument to Post Installation**  
DWG. NO. **PEG-INSTALL**

REVISION: B  
SCALE: 1:16  
DATE: 3/23/2018  
SHEET 2 OF 4

ITEM NO.	PART DESCRIPTION	In Ground - Recycled Post/QTY.	In Ground - Steel Post/QTY.	Surface Mount Recycled Post/QTY.	Surface Mount Steel Post/QTY.
1	Pegasus Instrument Assembly	1	1	1	1
2	Small SS Holster	2	2	2	2
3	In Ground Recycled Post, 72"lg.	2	-	-	-
4	In Ground Steel Post, 72"lg.	-	2	-	-
5	Surface Mount Recycled Post, 36"lg.	-	-	2	-
6	Surface Mount Steel Post, 36"lg.	-	-	-	2
7	Surface Mount Base, For Recycled Post	-	-	2	-
8	#8 Flat Head Screw, .5"lg. SS, T15 tamp	8	8	8	8
9	#8 Button Head Screw, 1.25"lg. SS, T15 tamp	10	-	10	-
10	#10-24 Button Head Machine Screw, 1"lg. SS, T25 tamp	-	10	-	10
11	5/16" Hex Head Lag Bolt, 5"lg. SS	-	-	4	-
12	3/8"-16 Wedge Expansion Anchor, SS	-	-	8	8
13	35/64" Hex Nut Cap	-	-	8	8
14	Security Driver	1	2	1	2

**Step 1:** Start by mounting the Holsters to the Instrument Back with the provided #8 Flat Head Screws and Driver. The Back comes predrilled. Screw heads should be flush with the Holster surface when properly installed. Holster should also be flush along the back. Drive Screws slowly to prevent stripping.

**Step 2:** With two people, situate the Instrument with Holsters installed onto the Posts. Posts come predrilled and/or tapped. Fasten the Instrument to the Posts with the provided #8 Button Head Screw for Recycled Posts or #10-24 Button Head Machine Screw for Steel Posts. Drivers are provided.



**DETAIL B**  
SCALE 1 : 4

**DETAIL A**  
SCALE 1 : 4


**Step 1:** Excavate two 10" diameter holes, 36" deep, and 32" on center at the installation location. Contractor can modify Post to desired height. **Post Length = Frost Depth (36" Recommended) + Finished Post Height**

**Finished Post Height Guideline:** (Ages 3-5, 22") (Ages 5-7, 27") (Ages 7-11, 32") (Adult, 36")

**Step 2:** With two people, lower the Posts with the Instrument attached into the excavated holes.

**Step 3:** Verify the correct placement, levelness, and finished height of the Instrument. Check for sufficient clearance around the Instrument, a 36" perimeter around the Instrument is recommended for wheelchair accessibility.

**Step 4:** Last pour concrete around the posts. It is recommended to brace the Instrument to hold it rigid while the concrete cures. Leave to set according to the concrete manufacturers guidelines. Approximately (6) 80lb. bags will be needed.



TITLE:  
**In Ground Installation**

DWG. NO. PEG-INSTALL

REVISION: B

SCALE: 1:16

DATE: 3/23/2018

SHEET 3 OF 4

**Step 1:** Standard height for Surface Mount Posts are 36". The Recycled Posts may be modified in the field to the following heights:  
 (Ages 3-5, 22") (Ages 5-7, 27") (Ages 7-11, 32") (Adult, 36")  
 The height of Surface Mount Steel Posts can not be adjusted.

**Step 2:** Determine installation location. Verify concrete footing is a minimum of 48" long x 24" wide x 6" thick. If the concrete pad is at an angle, steel washers are required to act as shims (Shims not provided). If there is not already an existing pad, approximately (7) 80lb. bags will be needed. Allow concrete to cure per concrete manufacturers guidelines.

**Step 3 (Recycled Post Only):** Install the Surface Mount Bases to the bottom of the Posts. Align the holes on the Bases with the holes on the Posts. The Bases should fit snugly around the Posts. Fasten them together with the provided 5/16" Hex Head Lag Bolts.

**Step 4:** With two people place the Instrument Assembly with Posts attached onto the concrete pad and mark the center of the holes on the surface mount bases. After you have made your marks, set aside the Instrument in order to drill for anchor holes. With a hammer or rotary drill, drill through concrete at marked locations. Drill to a minimum depth of 4". A 3/8" masonry drill bit will be needed.

**Step 5:** Place the Instrument back over the drilled out holes. Insert provided anchor bolts into aligned holes. Position anchor nut so that it is flush with the top of the bolt. Pound anchor bolts into the hole until the anchor washer is flush with the surface mount bases. Tighten anchor bolts until they are snug. Cover remaining bolt sections with provided nut caps.

**Step 6:** Verify the correct placement, levelness, and finished height of the Instrument. Check for sufficient clearance around the Instrument, a 36" perimeter around the Instrument is recommended for wheelchair accessibility.

**Step 7:** If installing onto wet concrete, us the wet set anchor manufacturers guidelines for installation procedures.

